

For more information contact...

WOODFORD MANUFACTURING COMPANY

2121 Waynoka Road, Colorado Springs, Colorado 80915 • Phone: (719) 574-1101 • Fax: (719) 574-7621

To view our complete product line visit: www.woodfordmfg.com or email: sales@woodfordmfg.com

A Division Of WCM Industries, Inc.

04/10 Rev. 3

Model 22 Shower Faucet (Suffix-SF)

Typical Installation Instructions

Manufactured under one or more of the following U.S. Patents:
6,206,039B1; 5,632,301; 5,590,679

When suffix-SF Shower Faucet configuration is ordered, a 3/8" NPT hole is drilled and tapped into the top of Model 22, which will accept a 3/8" riser pipe, shower arm and shower head (all items shown in dashed lines, furnished by others).

1. Install the Shower Faucet in a desired location using normal faucet installation procedures.
2. After Shower Faucet is properly installed and anchored, install riser pipe, shower arm and shower head to desired height.
3. To keep riser pipe from being damaged, a pipe bracket should be used to secure riser pipe to wall .
4. Use a hose threaded cap, (not furnished), and cap the outlet nozzle. **NOTE: Turn off unit and remove Nozzle Cap to drain.**

